

The logo for Frekote, featuring a stylized circular icon composed of three concentric arcs on the left, followed by the word "FREKOTE" in a bold, white, sans-serif font with a registered trademark symbol (®) to its upper right. The logo is set against a green rectangular background.

FREKOTE®

A large, high-angle photograph of the nose and cockpit of a white commercial airplane in flight against a clear blue sky. The aircraft's wings and engines are partially visible on the left side.

Frekote® 44-NC™ Wipes

*High Performance
Release Agent Wipes for
Composite Assemblies*

Frekote® 44-NC™ Wipes are pre-saturated with Frekote® 44-NC™, a semi-permanent, non-migratory release system that chemically bonds to the mold surface to form a microthin film, which is stable at temperatures exceeding most molding processes. These wipes should be your first choice release agent for a non-contaminating release coating. They are pre-packaged and the easy pack design allows pre-saturation prior to use, thus extending the usable shelf life of the wipe. Frekote® 44-NC™ Wipes can be used for the release of thermoset and prepreg epoxies, polyester resins, thermoplastics, adhesives, and rotational molded plastics.

The Henkel logo, consisting of the word "Henkel" in a bold, white, sans-serif font inside a red oval with a white border.

Henkel



Frekote® 44-NC™ Wipes

*High Performance
Release Agent Wipes for
Composite Assemblies*

Features and Benefits

- Convenient package for single wipe use provides for optimum usage of chemistry
- Easily applied at room temperature
- High quality lint-free wipe cloths
- May be used for touch-up applications
- Improved storage stability, 9 months from Date of Manufacture for product stored at room temperature

Ordering Information

Item Number	Container Size	Pcs/Case
987545	1 Case (20 packs with 10 wipes/pack)	200



Visit the web for
immediate access to:

- Distributor Information
- Material Safety Data Sheets
- Technical Data Sheets
- Product Literature

For technical product assistance, call 1-800-562-8483.

Henkel Corporation
1001 Trout Brook Crossing
Rocky Hill, CT 06067
U.S.A
www.henkelna.com



Operation and Application

- We strongly suggest that new molds be prepared and used molds be thoroughly cleaned and sealed prior to use. Please refer to the Technical Data Sheet for Frekote® 44-NC™ for detailed instructions.
- Burst dual-pack design. Squeeze fluid side in direction of wipes until burst. Make sure that all liquid (Frekote® resin) flows to the wipe compartment. Allow 5 minutes to ensure saturation of the wipe cloths with Frekote® resin.
- Using proper protective equipment, remove wipes for use.
- Wipe on a smooth, uniform, thin, continuous wet film to the mold surface. Avoid wiping over the same wet areas until the solvent has had a chance to evaporate.
- Apply two to three base coats allowing at least 15 minutes between coats to dry.
- Apply one final uniform coat and allow to cure for a minimum of 3 hours at room temperature or 15 minutes at 100°C-150°C prior to use.
- Maximum releases may be obtained by seasoning the mold (recoating once after the first few initial pulls).
- Use additional wipes as a touch-up on areas giving difficult release.